

---

## 50 l nutch filter unit

---



### Characteristics:

- batch-wise filtration of solutions
- parts in contact with product made entirely of 3.3 borosilicate glass and PTFE
- 50 l batch volume
- DN 400 filter plate and vessel
- manual agitation, with paddle agitator, height-adjustable design
- KAMLOK couplings for feed and solvent nozzles,
- pressure measurement
- disc-burst protection against impermissible overpressure
- bottom outlet valve
- mobile stainless steel frame for easy assembly and disassembly,
- manual lift and swivel fittings on the lower part of the apparatus
  - for removing filter cake
  - for exchanging and tensioning the filter cloth
- fully preassembled package unit
- directives
  - CE compliance / machinery directive
  - pressure equipment directive 97/23 EC
  - FDA material certificates