

---

## NW 300 / 450 gas scrubber

---



### Characteristics:

- NW 300 gas scrubber with NW 450 column sump
  - 3.3 borosilicate glass RASCHIG packing
  - 3.3 borosilicate glass disperser and packing support
  - easy to clean
- PTFE demister for avoiding droplet entrainment
- corrosion-resistant packing retainer
- production of specified acids through targeted absorption with VE water
- optional transfer operation to reduce VE water consumption
- specified temperature control
- TA-Luft-compliant depletion of the process flue gas
- tubing and measuring technology including connection to existing receiver and collection tanks
- process control
- directives
  - pressure equipment directive 97/23 EC
  - FDA material certificates
  - TA-Luft (German technical instructions on air quality control) compliant connections and fittings