

---

## vertical settler 0,5 – 10 l

---



### Characteristics:

- settler 0,5 l – 10 l, made of borosilicate glass 3.3 / PTFE
  - vertical design with small hold-up, especially for distillation and rectification tops with small distillate mass flow
  - with phase level adjustment of the two liquid phases via syphon
  - with draining valve
  - with feed nozzle and integrated deaeration
  - easy inverse phase operation by turning the apparatus
- optional conductive coating and earthing
- optional feed distributor
- optional piping and valves for the settler
- optional rack and holders for apparatus and piping
- directives & guidelines
  - CE machinery directive
  - pressure equipment directive 97/23 EC
  - ATEX
  - TA-Luft conformity for connections and valves